

PLEASE READ THIS LICENSE CAREFULLY

This license governs use of the accompanying firmware. If you use the device, you accept this license. If you do not accept the license, do not use the device.

The embedded devices firmware ("Software") is licensed, not sold, to you by Nu Tech Software Solutions, Inc. ("Nu Tech Software Solutions") for use only under the terms of this License, and Nu Tech Software Solutions reserves any rights not expressly granted to you. You own the device on which the Software is stored, but Nu Tech Software Solutions, its licensors and sub-licensors retain ownership of the Software itself.

1. Definitions

The terms "reproduce," "reproduction" and "distribution" have the same meaning here as under U.S. copyright law. "You" means the licensee of the software. "Your company" means the company you worked for when you downloaded the software. "Reference use" means use of the software by you or within your company as a reference, for the sole purposes of developing your product, debugging your products, maintaining your products, or enhancing the interoperability of your products with the software, and specifically excludes the right to distribute the software outside of your company or to any third party.

2. Grant of Rights

(A) Copyright Grant- Subject to the following terms and conditions, Nu Tech Software Solutions grants to the end user ("You") a non-exclusive, non-transferable, fully paid and royalty-free license, without the right of sublicense, to use the Product solely in the form of the binary firmware image provided, only to the extent necessary to use the AD2USB hardware. Notwithstanding the foregoing, this License does not apply to the source code or object code of the Product. This license is not a sale. You may not rent, lease, or lend the Product. Nu Tech Software Solutions may cancel this LICENSE if you do not abide by its terms and conditions. This LICENSE applies to updates or supplements to the original Product, unless we provide other terms along with the update or supplement.

RESERVATION OF RIGHTS. Nu Tech Software Solutions reserves all rights not expressly granted to you in this LICENSE. Title and copyrights to the Product remain with Nu Tech Software Solutions.

3. Limitations

(A) No Trademark License- This license does not grant you any rights to use the Licensor's name, logo, or trademarks.

(B) If you begin patent litigation against the Licensor over patents that you think may apply to the software (including a cross-claim or counterclaim in a lawsuit), your license to the software ends automatically.

(C) LIMITATION ON REVERSE ENGINEERING, DECOMPIATION, AND DISASSEMBLY. You may not reverse engineer, decompile, or disassemble the Product. You may not copy the Product or transfer it to other devices without the express prior written consent of Nu Tech Software. Notwithstanding any prior agreement you may have with Nu Tech Software.

(D) The software is licensed "as-is." You bear the risk of using it. In no event will Nu Tech Software Solutions, its parent or subsidiaries or any of the licensors or sub-licensors, directors, officers, employees or affiliates of any of the foregoing be liable to you for any consequential, incidental, indirect or special damages whatsoever (including, without limitation, damages for loss of business profits, business interruption, loss of business information and the like), whether foreseeable or unforeseeable, arising out of the use of or inability to use the Software or accompanying written materials, regardless of the basis of the claim and even if Nu Tech Software Solutions or a Nu Tech Software Solutions representative has been advised of the possibility of such damage. Nu Tech Software Solutions' liability to you for direct damages for any cause whatsoever, and regardless of the form of the action, will be limited to replacement of the Software that caused the damages. THE LIMITATION WILL NOT APPLY IN CASE OF PERSONAL INJURY ONLY WHERE AND TO THE EXTENT THAT APPLICABLE LAW REQUIRES SUCH LIABILITY. BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

4. General

(A) This License will be construed under the laws of the State of Oregon. If any provision of this License shall be held by a court of competent jurisdiction to be contrary to law, that provision will be enforced to the maximum extent permissible, and the remaining provisions of this License will remain in full force and effect. If you are a U.S. Government user, then the Software is provided with " RESTRICTED RIGHTS" as set forth in subparagraphs (c)(1) and (2) of the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19 or subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7013, as applicable. Manufacturer: Nu Tech Software Solutions, 11575 SW Pacific HWY, Suite 109, Tigard, Oregon 97223

5. Termination


(A) This License is effective until terminated. This License will terminate immediately without notice from Nu Tech Software Solutions or judicial resolution if you fail to comply with any provision of this license. Upon such termination you must destroy the Software, all accompanying written materials and all copies thereof, and Sections 3, and 4 will survive any termination.

See also the full color quick start guide and other guides at
http://www.nutech.com/forums/ad2usbstart.html

Before you start...

Please take a moment and read this manual before you install the AD2USB to your alarm panel. Rushing into the install of devices like this can result in damage to the device or accidental activation of your alarm and alerting of your alarm company.

Please use caution when using this device. It's easy to press the wrong keyboard character and have the alarm panel issue a silent alarm to your alarm company. You should have your alarm in testing mode prior to installing this device or when testing with this device.



* provided case not shown.

* provided locking screws and case not shown

Introduction

Thanks for purchasing the AD2USB Ademco to Computer interface board. The AD2USB device was designed to work with a wide range of Ademco Vista alarm panels. The AD2USB device only consumes ~7mA. You can use this value to calculate the total number of devices your panel will support.

The device presents itself to your computer as a virtual serial port running at 115200,8,N,1¹. Drivers for your operating system are required.

¹The AD2SERIAL Adapter operates at a different baud rate (19200,8,N,1)

New Video Tutorials!

- AD2USB To Panel: http://tinyurl.com/cy9nr7
AD2USB To PC: http://tinyurl.com/blpu8vv
AD2USB To MAC: http://tinyurl.com/d6wk3c7

Drivers

If you are running windows you can get the Virtual COM port drivers from FTDI <http://www.ftdichip.com/Drivers/VCP.htm>. Install version 2.08.08 or newer. With windows Vista after you install the driver you need to select the device under device manager and select its properties. Then advanced tab and enable the VCP driver. In many cases your computer may already have this driver if you have ever used an FTDI based USB2Serial device as many of them are based upon FTDI chips.

If you are running Linux you can use the `ftdi_sio` driver. This should automatically load when you connect the device if you are using a relatively new distribution of Linux. For OSX and many other operating systems the drivers can be found at <http://www.ftdichip.com/FTDrivers.htm>

Alarm Panel Programming

If you have an older SE based panel then addressing is not used and it is not necessary to change any panel programming for the AD2USB to operate.

With all other panels You will need to configure the alarm panel with the address of the AD2USB as a new keypad device. For example, the default keypad address for a Vista 15P is 16. The AD2USB is factory configured for device address 18 if this is already used on your panel see "Configuration your AD2USB" section on how to change this.

If your alarm panel does not have a spare keypad configured, you will have to configure it for one. In this case, you can 1) call your security monitoring company and ask them to add in a new keypad - (ask them what address they configured it to); or 2) if you know the Installer Code, you can program it in yourself. You should reference the Programming Guide and Installation and Setup Guide for your unit. (I found these at www.aesecurity.com/manuals.html)

Connecting The AD2USB/AD2SERIAL To The Panel and Computer

Connect the 12v,GND,DI(GREEN),DO(YELLOW) on the panel to the 12v,GND,DI,DO on your AD2USB. Do not cross the DO/DI lines. The DO on the panel connects to the DO on the AD2USB. The device gets power from the alarm to operate. We suggest you perform this connection while the alarm panel is powered down and the battery is disconnected.

When power is connected to the AD2USB it should have a steady LED heartbeat indicating the devices is looking for messages from the panel.

Connect the AD2USB to a computer. You should see it install some new hardware or give some indication that a new devices was installed in a log file. It will be a COM port. You can see this COM port under your device manager on windows or using the `dmesg` command under Linux, OSX or other Unix based operating systems.

Try to communicate with the device directly with a serial terminal program. The program I have used for years and trust is Putty. <http://www.chiark.greenend.org.uk/~sgtatham/putty/download.html>. Under Linux you can use `minicom` using the `-o` option to prevent any modem initialization being done. On OSX you can use the `screen` command.

Pick the COM port that was added, say COM3, using `115200,8,N,1#`. You should now see some text spewed at you. You can press the = character in your terminal program to reset the device and verify you can send data to the AD2USB correctly. Depending on your terminal software You may need to press ENTER to instruct the terminal program send it to the AD2USB. If your terminal program operates in character mode the enter is not necessary.

[#]The AD2SERIAL Adapter operates at a different baud rate (19200,8,N,1)

Configuring Your AD2USB

You may need to set the devices address on your AD2USB. For example the default keypad address for a Vista 15P is 16. As with a normal keypad you have to tell the AD2USB what address it is configured for. By default the AD2USB device is factory configured for address 18. If you already have a device at 18 you will need to change the AD2USB devices address.

To do this just press **!** in your terminal program to configure the AD2USB and set the address. If you have an SE panel you must set this to 31 or you will not see any messages from the panel. Never have two devices share the same address except for the SE panels where addressing is not used. You can leave the panel code blank or 0's as this is currently not used and press ENTER through any configuration options you a don't want to change.

If you now press ***** into your terminal program your panel should respond as if you hit the same key on your alarms keypad.

If it appears to take a long time for the send... operation, this probably means that the alarm panel is not recognizing the AD2USB or a device conflict exists. Check the programming of the alarm panel and the AD2USB configuration have the same address. Also make sure no other devices exist at the same address as the AD2USB.

The AD2USB should see all messages from the alarm panel regardless of programming of the panel. If you are not seeing messages after connecting the AD2USB to your panel you either have a wiring issue or you have an SE panel and you have not set your AD2USB to address 31.

Post installation

Sample code and programs are available in the forums on our site here <http://www.nutech.com/forums/contribute.html>

API and Configuration documentation can be found here <http://www.nutech.com/forums/ad2usbapi.html>

The free virtual keypad software called AD2USBGUI that runs on many operating systems is here <http://www.nutech.com/forums/ad2usbgui.html>. It is written in C#/Mono and will require Gtk# and (Microsoft@ .NET 2.0 or Mono) to run. You can get Gtk# from <http://www.go-mono.com/mono-downloads/download.html>

We also now have available to purchase an alarm panel unlocker module for AD2USBGUI. This program when used with this device will determine the master installer code and any other codes on the alarm panel.

For questions and support email ad2usb@support.nutech.com. We try to respond to emails in the same day that we get them.

TRADEMARKS

Ademco is a registered trademark of Honeywell International Inc.

AD2USB and AD2SERIAL are a registered trademark of Nu Tech Software Solutions, inc.

All brands or product names are the property of the respective owners.